

# Mouse sAPPβ-w Assay Kit - IBL

96 Well

Please read carefully this instruction prior you use this assay kit.

#### **INSTRUCTIONS FOR USE**

This product is for research use only and is not intended for diagnostic use.

#### KIT COMPONENT

1	Precoated plate: (Anti-sAPPβ-w Rabbit IgG)	96Well x 1
2	Labeled antibody conc.:	
	(30X) HRP conjugated Anti-mN-APP Rabbit IgG Fab' A.P.)	0.4mL x 1
3	Standard: (Recombinant Mouse sAPPβ-w	0.5mL x 2
4	EIA buffer	30mL x 1
5	Solution for labeled antibody	12mL x 1
6	Chromogen: TMB solution	15mL x 1
7	Stop solution	12mL x 1
8	Wash buffer conc.	50mL x 1

## **MESUREING SAMPLES**

Mouse plasma, Cell Culture Supernatant

#### **PRINCIPLE**

This kit is a solid phase sandwich ELISA (Enzyme-linked Immunosorbent Assay). As a primary antibody is coated on a plate, samples and standard are added into the wells for 1<sup>st</sup> reaction. After the reaction, HRP-conjugated secondary antibody is added into the wells for 2<sup>nd</sup> reaction. After washing away unbound the secondary antibody, Tetra Methyl Benzidine (TMB) is added to the wells and color develops.

#### **OPERATING PRECATION**

- 1 Test samples should be measured soon after collection. For storage of samples, store them frozen and do not repeat freeze/thaw cycles. Thaw the test samples at a low temperature and mix them completely before measurement.
- 2 Test samples should be diluted with "4, EIA buffer" contained in this kit.
- 4 Standard curve should run for each assay.
- 5 Use test samples in neutral pH range. The contaminations of organic solvent may affect the measurement.
- 6 All reagents should be brought to room temperature (R.T.) and mixed completely and gently before use. After mixing them, make sure of no change in quality of the reagents.
- 7 Use only "8, Wash buffer conc." contained in this kit for washing the precoated plate. Insufficient washing may lead to the failure in measurement.
- 8 Fill the wash buffer each well, invert the plate and make sure the liquid is completely removed by shaking it off if you use a washing bottle. Repeat this washing process several times as instructed in order to avoid any insufficient washing process.
- 9 After remove the wash buffer, tapping the plate against a clean paper towel for completely removing the liquid from the wells and make sure the paper towel is not contact with inside of the wells in this process.
- 10 "6, Chromogen TMB solution" should be stored in the dark due to its sensitivity against light. It should be also avoided contact with metals. Required quantity should be prepared into a collecting container for each use.
- After adding TMB solution into the wells, the liquid in the wells gradually changes the color in blue. In this process the plate should be in dark. Remained TMB solution in the collecting container should not be returned into the original bottle of TMB solution to avoid contamination.
- 12 Measurement of O.D. should be done within 30 minutes after addition of "7, Stop solution".

# **OPERATION MANUAL AND DOSAGES**

1. Materials needed but not supplied.

Plate reader Micropipette and tip
Test tubes for dilution Measuring cylinder and beaker
Deionized water Plate washer
Paper towel Collecting container
Refrigerator (i.e. clean disposable test tube)

## 2. Preparation

(1) Preparation of wash buffer

Dilute "8, Wash buffer conc." 40 fold with deionized water. The diluted one is used for the assay as a wash buffer. Adjust the required quantities if needed.

(2) Preparation of labeled antibody

Dilute "2, Labeled antibody conc." 30 fold with "5, Solution for labeled

antibody" using a prepared collecting container.

### (3) Preparation of standard

Add 0.5 mL of deionized water into the vial of "3, Standard" and completely dissolve it. Concentration of the standard is 1600 pg/mL. Prepare 7 test tubes for dilution of the standard and adding 230  $\mu$ L of the

EIA buffer into each tube.

Put 230  $\mu$ L of 1600 pg/mL standard into the tube 800 pg/mL (Tube-1) and gently mix it. Afterword, put 230  $\mu$ L of the mixed liquid of tube-1 into the tube 400 pg/mL (Tube-2) and gently mix it. Dilute two fold standard solution in series to set up 7 points of diluted standard between 800 pg/mL and 13 pg/mL.

Tube-1	800	pg/mL
Tube-2	400	pg/mL
Tube-3	200	pg/mL
Tube-4	100	pg/mL
Tube-5	50	pg/mL
Tube-6	25	pg/mL
Tube-7	13	pa/ml

(4) Preparation of test samples

Dilution Ration of Mouse plasma: 10 fold

## **3 MEASUREMENT PROCEDURE**

(1) Add test sample blank

Determine wells for test sample blank. Put 100µL each of "4, EIA buffer" into the wells.

(2) Add prepared test samples and standard

Put 100  $\mu L$  prepared test samples and 100  $\mu L$  prepared standard into appropriate wells.

- (3) Incubation with plate lid (1st reaction).
- (4) Washing

Wash the plate with the prepared wash buffer and remove all liquid.

(5) Add prepared labeled antibody

Put 100 µL prepared labeled antibody into the wells.

- (6) Incubation with plate lid (2<sup>nd</sup> reaction).
- (7) Washing

Wash the plate with the prepared wash buffer and remove all liquid completely.

(8) Add "6, Chromogen - TMB solution"

Put 100  $\mu L$  the TMB solution into the wells.

- (9) Incubation in dark
- (10) Add "7, Stop solution"

Put 100 µL the Stop solution into the wells.

(11) Determination of optical density (O.D.)

Remove any dirt or drop of water on the bottom of the plate and confirm there is no bubble on the surface of the liquid. Then, measure the both O.D. of standard and the test samples against a test sample blank.

Measurement wavelength: 450 nm. In case of 2 wavelengths:

Main wavelength is 450nm. Sub-wavelength is between 600 and 650 nm.

Table for measurement procedure

Table for measurement procedure			
	Test samples	Standard	Test sample blank
Reagents	Test samples 100 μL	Diluted Standard 100 µL	EIA buffer 100 μL
1 <sup>st</sup> reaction	Incubation overnight at 2~8°C with plate lid.		
Washing	4 times (wash buffer more than 350 μL)		
Labeled antibody	100 μL	100 μL	100 µL
2 <sup>nd</sup> reaction	Incubation for 60 minutes at 2~8°C with plate lid.		
Washing	5 times (wash buffer more than 350 μL)  100 μL  100 μL  100 μL  Incubation for 30 minutes at R.T. (shielded).		han 350 μL)
TMB solution			100 µL
Chromogenic reaction			
Stop solution	100 µL	100 µL	100 µL
Measuring O.D.	450 nm / 600∼650 nm		


## **CALCULATION OF TEST RESULT**

- 1 Plot the concentration of the standard on the x-axis and its O.D. on the y-axis. Draw a standard curve by applying appropriate regression curve on each plot (i.e. quadratic regression of double logarithm conversion).
- 2 Read the concentration by applying the absorbance of the test samples on a standard curve.
- 3 Calculate the concentration of the test samples by multiplying dilution ratio of test samples on the value.



Example of standard curve and measured value

Standard (pg/mL)	O.D. (450nm)		
800	2.136		
400	1.419		
200	0.830	OD 450	
100	0.483	C	
50	0.283		
25	0.178		
13	0.125		
		•	





### PERFORMANCE AND CHARACTERISTICS

### 1 Sensitivity 2.87 pg/mL

### 2 Measurement range 13 ∼ 800 pg/mL

10





4 Intra-assay

T IIII a accay			
Measurement value (pg/mL)	SD (pg/mL)	CV (%)	n
591	24.4	4.1	24
159	6.6	4.1	24
52	2.9	5.7	24

5 Inter-assay

Measurement value (pg/mL)	SD (pg/mL)	CV (%)	n
642	37.2	5.8	6
168	7.5	4.5	6
50	1.5	3.1	6

#### 6 Specificity

Substance	Cross reactivity (%)
Mouse sAPPα	<1%

### PRECAUTION FOR INTENDED USE AND/OR HANDLING

### 1 Precaution for handling (Hazard prevention)

- (1) Treat the components carefully and wash hands after handling it.
- (2) "7, Stop solution" is a strong acid substance (1N Sulfuric acid). Therefore, it should be careful for the treatment and do not contact your skin and clothes with it. It also needs to pay attention to the disposal of it.

#### 2 Precaution for intended use

- (1) "3, Standard" is lyophilized products. It should be careful to open this vial.
- (2) All reagents should be stored at 2 8°C.
- (3) Precipitation can be seen in "4, EIA buffer", "5, Solution for labeled antibody" and "8, Wash buffer conc.", however, it does not affect its performance.
- (4) Do not mix or replace the reagents with the reagents from a different lot or kit.
- (5) Do not use expired reagents.

### 3 Precaution for disposal

(1) Dispose used materials after rinsing them with large quantity of water.

## STORAGE AND THE TERM OF VALIDITY

Storage Condition: 2 - 8°C

The expiry date is specified on the outer box.

## PACKAGE UNIT AND PRODUCT NUMBER

Package unit: 96 Well Product number: 27416

# REFERENCES

- 1. Selkoe DJ. Normal and abnormal biology of the beta-amyloid precursor protein. Annu Rev Neurosci. 1994;17:489-517.
- 2. Citron M, Oltersdorf T, Haass C, McConlogue L, Hung AY, Seubert P, Vigo Pelfrey C, Lieberburg I, Selkoe DJ. Mutation of the beta-amyloid precursor protein in familial Alzheimer's disease increases beta-protein production. Nature. 1992 Dec 17;360(6405):672-4.
- 3. Hsiao K, Chapman P, Nilsen S, Eckman C, Harigaya Y, Younkin S, Yang F, Cole G. Correlative memory deficits, Abeta elevation, and amyloid plaques in transgenic mice. Science. 1996 Oct 4;274(5284):99-102.

# **CONTACT DETAILS**



Distributed By:

IBL-America, Inc.

8201 Central Ave NE, Suite P
Minneapolis, MN 55432, USA

info@ibl-america.com

(888) 523 1246